
Installation Guide

Omegalume® 5000 / Extended Arm





- READ THE PROVIDED INSTRUCTIONS PRIOR TO INSTALLING.
- · INSTALLATION SHOULD BE CARRIED OUT BY QUALIFIED INSTALLERS.
- THE INSTALLER HAS THE FINAL RESPONSIBILITY FOR THE STRENGTH AND RIGIDITY OF THE WALL/CEILING STRUCTURE.
- A MINIMUM OF 2 PEOPLE REQUIRED WHEN INSTALLING LONG LENGTH FIXTURES.




Mount Instructions




1 MOUNT EXTENDED ARM SWIVEL PLATE(S) TO SURFACE

 MEASURE AND MARK THE SURFACE ACCORDING TO THE "FIXTURE MOUNTING SPECIFICATIONS" CHART (BELOW) TO ENSURE ACCURATE PLACEMENT OF EXTENDED ARM SWIVEL MOUNT PLATES(S).
BEFORE MOUNTING TO SURFACE, ENSURE STEP #2 IS COMPLETED FIRST.





2 FEED WIRE(S)

• FEED WIRE FROM EXTRUSION SWIVEL, INTO WIRE THRU HOLE ON THE EXTENDED ARM SWIVEL MOUNT, AND OUT THROUGH THE WIRE THRU HOLE ON THE EXTENDED ARM SWIVEL MOUNT PLATE.



Mount Instructions





BACK VIEW